Get comfortable in your **Drive**™ chair.



- **Seat Depth Adjustment**
  Lift paddle under left side of seat. Slide seat forward or backward. Release paddle.

- **Arm Height**
  Lift up on trigger, raise or lower to desired height.

- **Arm Width**
  Grasp arm caps, flip them over.

- **Upright Back Lock**
  Lean forward, rotate outer ring of **3 in 1 Control**™.



- **Seat Height Adjustment**
  To raise, lift your weight off the seat and squeeze outer ring of **3 in 1 Control** toward your palm. To lower, squeeze outer ring.

- **Back Tension Adjustment**
  Turn soft knob of **3 in 1 Control** forward to increase tension, backwards to decrease.

- **Lumbar Adjustment**
  Lean forward to slide handle up or down to desired position.